

Updating the Winflows Database

Periodically GE may upload an updated version of the database to the website. *This does not require you to re-download the Winflows software.* This newer version of the database may contain new products or slight adjustments to existing products if and when required. Make sure you check the site periodically to ensure you have the most recent database especially if you are looking for a product that was recently launched by GE.

Please follow the steps below to successfully update your Winflows Database.

1

Close your Winflows application.

2

Download the updated file from www.gewater.com/winflows.jsp to your computer.

3

Locate the existing database called winflows.mdb on your machine. This existing database will be typically in stored at C:\Program Files\GE\Winflows\bin or wherever you chose to save the Winflows program originally.

4

Rename this file to identify it as an older version such as WinflowsOld.mdb. It can be deleted, but it is good to save it for a few days just in case there is an unexpected error with the new database.

5

Copy the new database to this folder.

